

















Remote Control Settings	Button	Remarks
-------------------------	--------	---------

Remote Control Settings	Button	Remarks
		Press the "ON/OFF" button, the light goes to constant on/off mode, sensor is disable. Short press the "M/R" button, the sensor starts to work.
		Short press "M/R" button, all parameters back to the last settings. Long press "M/R" button, all parameters back to factory settings.
		Stand-by dim level Set up stand-by dim level: 10%/ 30%
		Detection Area Set up detection area: 25%/ 50%/ 100%
		Short press "DIM+/DIM-" button to transmit dimming signal. The brightness of the lamp adjust at 5% per unit, from 50% to 100%.
		Stand-by period Set up stand-up time: 0s/ 1min/ 30min/ +∞
		Daylight sensor Set up daylight threshold: 5Lux/ 15lux/ 50lux/ disable
		Hold time Set up hold time: 5s/ 1min/ 5min/ 10min